

Transmitter Cross Reference Guide

Model	Part #	Date Code	Replacement Remote
Automate Auto-key	703M	6G - 6I	499T
Automate 1	705a	4A - 6D	None/uses factory remote
Automate 1	700a	6D - up	None/uses factory remote
Automate 2	420A	2K - 4H	493T
Automate 2	710A	5J - 6F	493C
Automate 2	710A	6G - 7D	492T
Automate 2 HF	710A	7E - up	491T
Automate 3	430A	Up to 2B	465T
Automate 3	430A	2C - 6C	493T
Automate 3+	432A	5L - 7E	492T
Automate 3+ HF	432A	7F - 9B	491T
Automate 4	440A	Up to 2J	465T
Automate 4	440A	3D - 4L	493t
Automate 5	435A	2E - 4F	493T
Automate 5+	437A	3L - 5K	493C
Automate 5+	437A	5L - 7E	492T
Automate 5+ HF	437A	7F - 8J	491T
Automate 5 HF	438A	4G - 7C	491T
Automate 6	445A	Up to 3B	465T
Automate 6	445A	3E - 5A	493T
Automate 6 HF	448A	4I - 6H	491T
Automate 6 HF	448A	7C - 8L	485T
Automate 7	280A	All	465T
Automate 7 HF	553A	6B - 6K	491T
Automate 7 HF	553A	7C - 8L	485T
Automate 8	281T	All	465T
Automate 10	710A	All	471T
Automate 15	415A	All	None/uses factory remote
Automate 25	425A	All	475T
Automate 35	435A	All	476
Automate 52	552A	All	476
Automate 53	553A	All	476
Equalizer 1	723E	6E	493T
Equalizer 1	725B	All	491T
Equalizer 2	432E	6A	493C
Equalizer 3	437E	5H	493C
Failsafe 3	703T	6G - 6I	499T
Hornet 121T	121T	4C - 8G	493T
Hornet 553T	553T	7H - 8B	491T
Hornet 700T	700T	6A - up	None/uses factory remote
Hornet 705T	705T	4G - 6A	None/uses factory remote
Hornet 706T	706T	4A	NO REMOTE/ NOT RF
Hornet 707T	707T	2F - 4A	NO REMOTE/ NOT RF
Hornet 710T	710T	All	465T
Hornet 715T	715T	All	465T
Hornet 717T	717T	2G - 3D	465T
Hornet 718T	718T	2E - 2K	NLA
Hornet 718T	718T	3D - 6D	493T
Hornet 718T	718T	6G - 7B	492T
Hornet 719T	719T	2C - 3B	NLA
Hornet 719T	719T	3D - 6D	493T
Hornet 719T	719T	6F - 7C	492T
Hornet 719T	719T	7D - 7J	491T
Hornet 720T	720T	2C - 3C	NLA
Hornet 720T	720T	3E - 6A	493T
Hornet 720T	720T	7J - up	491T
Hornet 721T	721T	2J - 2L	493T
Hornet 721T	721T	2J - 5E	493T
Hornet 722T	722T	2H - 4G	493T

Model	Part #	Date Code	Replacement Remote
Hornet 723T	723T	5G - 7E	493T
Hornet 725T	725T	7G - up	491T
Hornet 730T	730T	2E - 3K	465T
Hornet 730T	730T	3K-1 - 7A	493T
Hornet 730T	730T	7G - up	491T
Hornet 732T	732T	6C - 7E	492T
Hornet 732T	732T	7J - 9B	491T
Hornet 735T	735T	4C - 4G	493T
Hornet 737T	737T	4I - 5J	493C
Hornet 740T	281T	All	465T
Hornet 755T	755T	2B - 4G	465T
Pro Guard 2300	723G	6D - 6F	493T
Pro Guard 2500	725G	ALL	491T
Pro Guard 4700	437B	5B - 5G	493C
Pro Guard 4800	438B	5B - 5H	493C
Pro Guard 7100	271B	2L - 5A	484T
Pro Guard 7200	281B	2L - 4H	484T
Python 55	723B	6J - 7E	493T
Python 60	261S	2K - 4H	493T
Python 60	430P	4I - 6H	493T
Python 70	271S	2L - 5C	484T
Python 80	281S	2L - 5C	484T
Python 90	291S	2K - 4L	484T
Python 400 HF	410P	All	471T
Python 450 HF	552P	7H - 8L	491T
Python 450 ESP	552P	9B - up	471T
Python 625 HF	430P	8D - up	471T
Python 650 ESP	429P	9A - up	471T
Python 650	432P	5L - 7E	492T
Python 650 HF	432P	7F - 8B	491T
Python 650 HF	432P	8B - 9B	471T
Python 750	437P	5B - 5K	493C
Python 750	437P	5L - 7C	492T
Python 1000 HF	268S	4F-4H	491T
Python 1000 HF	438P	4G - 8B (a)	491T
Python 1000 HF	438P	8B - up	471T
Python PC 1000 HF	439P	7J - up	475T
Python 1500 HF	553P	5J - 7C	491T
Python 1500 HF	553P	7C - 7L	485T
Python 1500 HF	553P	8D - 8L	475T
Python 1500 ESP	553P	9B - up	475T
Python 2000 HF	371P	6A - 6F	485T
Python 3000 HF	381P	5H - 7L	485T
Python 3000 HF	381P	8B - up	475T
Sidewinder 1000	718B	3K	493T
Sidewinder 2000	719B	3K	493T
Sidewinder 2200	721B	3K - 5F	493T
Sidewinder 3000	720B	3K - 4H	493T
Sidewinder 3000 HF	410S	All	471T
Sidewinder 3200	722B	3K	493T
Sidewinder 3500 ESP	552S	9B - up	471T
Sidewinder 3500	552S	7H - 8L	491T
Sidewinder 4200	420B	2K - 5F	493T
Sidewinder 4200	420S	5B - 5F	493T
Sidewinder 4500 HF	430S	8D - up	471T
Sidewinder 5000 ESP	429S	9A - up	471T
Sidewinder 5000	432S	5L - 7E	492T
Sidewinder 5000 HF	432S	7F - 8B	491T
Sidewinder 5000 HF	432S	8B - 9B	471T

Transmitter Cross Reference Guide

Model	Part #	Date Code	Replacement Remote
Sidewinder 5200	430B	2H - 4E	493T
Sidewinder 6000	435B	2L - 4F	493T
Sidewinder 6000	437S	4J - 6H	493C
Sidewinder 6000	437S	6I - 7E	492T
Sidewinder 6000 HF(2 btn)	437S	7F - 7I	491T
Sidewinder 6000 HF	438S	4J - 8B (a)	491T
Sidewinder 6000 HF	438S	8D - 9B	471T
Sidewinder PC 6000 HF	439S	8B - up	475T
Sidewinder 6100	440B	2L - 3D	465T
Sidewinder 6200	445B	2L - 4H	493T
Sidewinder 6500 HF	553S	5K - 6H	491T
Sidewinder 6500 HF	553S	7A - 8B	485T
Sidewinder 6500 HF	553S	8D - 8I	475T
Sidewinder 6500 ESP	553S	9B - up	475T
Sidewinder 7000 HF	381S	5H - 7H	485T
Sidewinder PC 7000 SHF	381S	9E - up	475T
Sidewinder 7100	271B	2L - 5A	484T
Sidewinder 7200	281B	2L - 4H	484T
Steal Stopper 50	220S	All	465T
Steal Stopper 50/S	221S	All	465T
Steal Stopper 60	225S	Up to 2E	465T
Steal Stopper 60	261S	2E - 2I	493T
Steal Stopper 60/S	226S	All	465T
Steal Stopper PS 270	271S	Up to 2E	465T
Steal Stopper 70	271S	2F - 2J	484T
Steal Stopper PS 280	281S	up to 2E	465T
Steal Stopper 80	281S	EZSDEI280	484T
Steal Stopper 90	291S	2E - 2J	484T
Steal Stopper 1000	SS1000	All	465T
Steal Stopper 2000	SS2000	All	NO REMOTE/NOT RF
Steal Stopper PRO 3000	SS3000	All	NO REMOTE/NOT RF
Steal Stopper PRO 4000	SS4000	All	NO REMOTE/NOT RF
Steal Stopper PRO 5000	SS5000	All	465T (optional)
Steal Stopper 6001	SS6001	All	NO REMOTE/NOT RF
Wasp	718W	3F - 3H	NLA
Wasp	718W	4/95 - 5/95	NLA
Wasp	718W	6/95 - 10/95	465T
Wasp	718W	6F - 7C	492T
Wasp	718W	7D - up	491T
Valet 450T	450T	6D - up	NO REMOTE/ NOT RF
Valet 450R	450R	6D - 6I	485T
Valet 450R	450R	8D - up	475T
Valet 519T	519T	2J - 5J	465T / 493C
Valet 519T	519T	6A - up	492T
Valet 519H	519H	5A - 8H	491T
Valet 519H	519H	8L - up	471T
Valet 550T	550T	2G - 3B	NO REMOTE/ NOT RF
Valet 551R	551R	7G - 9A	491T
Valet 551R	551R	9B - up	471T
Valet 551T	551T	2K - up	NO REMOTE/ NOT RF
Valet 552T	552T	4I - 8J	491T
Valet 552T	552T	9A - up	491T
Valet 710T	710T	5G - 6F	493C
Valet 710T	710T	6G - 7D	492T
Valet 710T	710T	7E - 9B	491T
Valet 711T	711T	2C - 5K	465T
Valet 711T	711T	7E - up	491T
Valet 712T	712T	2J - 7D	465T

Model	Part #	Date Code	Replacement Remote
Viper 50	405V	All	NO REMOTE/NOT RF
Viper 100	410V	All	465T
Viper 100HF	410V	8G - up	471T
Viper 150	715V	All	465T
Viper 150 HF	552V	7H - up	491T
Viper 200	420V	Up to 2B	465T
Viper 200	420V	2C - 5J	493T
Viper 201	201V	All	465T
Viper 300 ESP	429V	9A - up	471T
Viper C 30	430C	2K - 5B	493T
Viper C 30	430C	2D - 2J	465T
Viper 300	430V	Up to 2B	465T
Viper 300	430V	2C - 7E	493T
Viper 300 HF	430V	7G - 8B	491T
Viper 300 HF	430V	8B - up	471T
Viper 300+	432V	5L - 7E	492T
Viper 300+	432V	7F - 8B	491T
Viper 300+ HF	432V	8B - up	471T
Viper 350 Classic	330V	Up to 2A	465T
Viper 350 Classic	330V	2B - 4E	493T
Viper 400	440V	Up to 2C	465T
Viper 400	440V	2D - 4L	493T
Viper 450 Classic	340V	Up to 2G	465T
Viper 450 Classic	340V	2H - 4B	493T
Viper 500	435V	Up to 2D	465T
Viper 500	435V	2E - 4C	493T
Viper C 50	437C	4C - 5K	493C
Viper C 50	437C	5L - 6C	492T
Viper 500+	437V	3I - 5K	493C
Viper 500+	437V	5L - 7E	492T
Viper 500 HF(Code Plus)	438V	4D - 7L	491T
Viper 500 HF	438V	8B - up	471T
Viper PC 500 HF	439V	7J - up	475T
Viper 500 NX	436V	5G	492T
Viper 550 Classic	335V	Up to 2C	465T
Viper 550 Classic	335V	2D - 4B	493T
Viper 550 HF	553V	5I - 6J	491T
Viper 550 HF	553V	7A - 8B	485T
Viper 550 HF	553V	8D - 9A	475T
Viper 550 ESP	553V	9C - up	475T
Viper C 60	445C	2D - 4L	493T
Viper 600	445V	Up to 2B	465T
Viper 600	445V	2C - 5E	493T
Viper 600 Classic	345V	Up to 2A	465T
Viper 600 Classic	345V	2C - 4B	493T
Viper 600 HF (Code Plus)	448V	4I - 6L	491T
Viper 600 HF (Code Plus)	448V	7A - 8B	485T
Viper 600 HF	448V	8B - 8L	475T
Viper PC 600HF	449V	9A - up	475T
Viper C 70 HF	448C	5E - 6D	491T
Viper Ultra 700	370V	up to 5C	484T
Viper 700 HF	371V	6A - 6F	485T
Viper Ultra 800	380V	up to 5A	484T
Viper 800 HF	381V	5H - 7L	485T
Viper 800 SHF	381V	8B - 8K	475T
Viper 800 ESP	381V	9A - up	475T
Viper Ultra 900	390V	Up to 4L	484T